

# LED PROJECTOR MANUAL



## INSTALL PROCEDURE

1. Install screws into support base
2. Plug in
3. Resolution adjustment



## INSERT/REPLACE GOBO

1. Unplug power cord.
2. Remove four screws to separate the radiator from the lamp body.



3. Remove the clasp and gently remove the lens.



4. Reinstall the radiator onto the lamp body and tighten all four screws.
5. You must lock the waterproof ring.

